

Installation Guide

1. Place the bag guard on the bag to mark the drilling points with the painters tape. (Fig.1)



Fig.1

2. Put painters tape on the drilling area to protect from scratches and to give a surface to mark the drilling points. (Fig.2)



Fig.2

* Pay attention when mark the drilling point on the rear, make sure the gap is uniform between the bag guard and the bag. (Fig.3)

3. Make the drilling points with an "X". Get your drill with a 7mm bit, center on the marks and drill all three holes. (Fig.4 & 5)



Fig.3

* Drill slowly, and stop drilling when the fiberglass is just drill through to avoid the carpet to be tear off, use a cutter to cut out the carpet instead of drilling.

4. Put the spacers and washers into the bolts accordingly as shown in Fig.6 and put them from the inside of the bag. Bolt the bag guards on; make adjustments before tighten the bolts by using a hexagonal key.(Fig.7)



Fig.4



Fig.7



Fig.6



Fig.5